




Assembly Guide



QUADRA



BF10 *Base Weights*


Thank you for purchasing Treasure Garden's Quadra base.
Please remove all contents from the package, inspect and review checklist.

CHECKLIST

A - (4) Quadra Base Weights

B - 220 lbs. All-Purpose Sand
(not included)

A -



B -



IMPORTANT:

- AG Universal Cross Bar Stand will not support umbrella without proper weight. Using the cross bar stand without weight will damage your umbrella and may cause injury.
DO NOT OPEN UMBRELLA UNTIL WEIGHTS ARE SECURED.
- Prior to assembly it is important to decide on the location of the umbrella.
- Allow ample height to avoid damage to your umbrella during assembly and usage.
- Choose a location that is level and sturdy.
- Avoid any sloping or soft ground.

Note:

- Some parts may be included in the styrofoam packaging. DO NOT discard any packaging or box until assembly is complete.

CAUTION: Fully assembled, the umbrella weighs *approximately 300 lbs.* Moving the umbrella fully assembled will increase the risk of damage to your umbrella and/or can cause serious injury. *We recommend a two-person team for assembly and disassembly.*

SAFETY PRECAUTIONS

- To reduce risk of personal injury in which a person is injured or harmed, and/or damage to personal property, read and follow the Assembly Guide prior to assembling and operating umbrella and base.
- Close and store the umbrella in windy conditions or when a storm approaches. Never allow the umbrella to flap in the wind; this could cause personal injury, damage to personal property, damage to umbrella and/or umbrella canopy. Do not use tilting function during windy conditions.
- Keep umbrella secured to umbrella base at all times.
- Do not leave open umbrella unattended. If damage occurs, this is not covered by the warranty.
- When adjusting the umbrella, make sure that no person(s), item(s) or personal property are close to the umbrella. This is important to prevent injury or material damage.
- Do not allow children to play on or with umbrella or umbrella base.
- When adjusting or assembling the umbrella or umbrella base, make sure fingers, toes or any other parts of the body are clear from moving parts. Failing to do so may result in serious injury.


STEP 1

FILL BASE WEIGHTS

- Remove 4 base weights from packaging and lay on soft surface (Fig. 1).
- Remove cap from each base weight by turning counter clockwise (Fig. 2) and fill with all-purpose sand (Fig. 3).
- Remove/clean any excess sand from base weight cap and threads. Secure cap on container by turning clockwise.

Note:


- Each base weight holds up to 55 lbs. of sand, 220 lbs. for all 4.



(Fig. 1)



(Fig. 2)




(Fig. 3)


STEP 2

ASSEMBLE BASE


- Select area to set assembled AG Universal Cross Base Stand.
- Be sure bottom pole stem is attached to cross bar stand and cross bars are adjusted to 20" position. (Please refer to umbrella manual for instructions.)
- Place each base weight onto AG Universal Cross Bar Stand (Fig. 4).
- Hook each section together so the base weights are secured in place (Fig. 5).
- Begin with middle sections first (Fig. 5) and work your way out (Fig. 6).
- Your base is now ready for umbrella installation. Please refer to umbrella manual for installation instructions.



(Fig. 4)



(Fig. 5)



(Fig. 6)

WARRANTY:

Treasure Garden warrants this product (for residential use ONLY) to be free from defects in original materials and workmanship for a period of 1 year from the date of purchase. If a defect in the original material or workmanship appears during the warranty period; Treasure Garden will (at its discretion) repair or replace the product without charge.

Simply contact your original authorized Treasure Garden dealer with a description of the defect. The dealer will verify the defect and work closely with Treasure Garden to obtain the necessary service. In many cases, simple problems can be solved with a replacement part that can be shipped directly to the dealer for professional installation / repair.

There are no serviceable parts within this product. Tampering with or altering the product will void warranty.

In the event that warranted factory service is required, Treasure Garden will assume the responsibility of the return freight charges for the first year only.

Returned product that (upon receipt and inspection) is deemed to be "not covered" under our warranty, will be shipped / billed at your expense.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

RUST: Rust is a natural part of the aging process of steel or iron based materials, and is therefore NOT considered a defect.

NOTE: Failure caused by unreasonable or abusive use, or failure caused by neglect of reasonable and necessary care are not covered by this warranty.

Additionally, acts of nature (including but not limited to wind, hurricanes, tornadoes, and storms) are not covered by this warranty.



www.treasuregarden.com

©2026 Treasure Garden, Inc. - All Rights Reserved.
v.05.13.26